

## RFID Reader RF-220

Rapid body camera allocation device



Connect an RFID reader RF-220 to a DockController DC-200 or EdgeController EC-220 to make body camera allocation quicker and easier, using your organisation's existing ID or access cards.


GENERAL INFORMATION	
Marketing name	RF-220
Typical usage	Attached to a DC-200 or EC-220 via USB connection
Management software	VideoManager 9.1 onwards (for High & Low frequency card support)
Warranty	1 year return to Motorola Solutions warranty
Includes snap-in holder	The Snap-in Holder is used to fix the RF-220 to a flat surface
Manufacturing information	Made For Motorola Solutions by ELATEC GmbH, Zeppelinstr. 1, 82178 Puchheim, Germany
	Model name: Elatec TWN4 MultiTech2 LF HF*

SIZE AND WEIGHT	
Dimensions	88 mm x 56 mm x 18 mm
Weight	115 g

TECHNICAL SPECIFICATIONS		
Frequency	Low Frequency: 134.2 kHz	
rrequeries	High Frequency: 13.56 MHz	
Read/write distance	Low Frequency and High Frequency: 100 mm (4 in)	
Supported compatible card standards	Including but not limited to: ISO1443A (e.g. MIFARE Classic) ISO14443B (e.g. HID iCLASS) ISO15693 (e.g. HID iCLASS SE) This includes Avigilon Control Manager	
	door access cards	
Operating temperature	0° to 40°C (32° to 104°F)	
Storage temperature	-55° to 70°C (-67° to 158°F)	

<sup>\*</sup>Customised configuration for Motorola Solutions





To learn more, visit: www.motorolasolutions.com/BWC



Motorola Solutions Ltd., Nova South, 160 Victoria Street, London, SW1E 5LB, United Kingdom

Available in APAC, EMEA, LATAM and NA.